


















Assembly instruction




TV Entertainment Unit - 120x30cm



													
∅6*38mm	∅15*11mm	∅8*40mm	ST3.5*14mm		M4*18mm								
A	24 PCS	B	24 PCS	C	20 PCS	D	75 PCS	E	2 PCS	F	2 PCS	H	4 PCS
													
J	2 PCS	K	2 PCS	L	5 PCS	M	4 PCS	N	1 PCS	P	5 PCS	R	8 PCS


1

2




ST3.5*14mm		M4*18mm				wooden leg	wooden leg	
D 43 PCS	E 2 PCS	F 2 PCS	J 2 PCS	K 2 PCS	L 5 PCS	M 4 PCS	N 1 PCS	P 5 PCS

±6*38mm	±15*11mm	±8*40mm
A 8 PCS	B 8 PCS	C 4 PCS




3

4








±6*38mm	±15*11mm	±8*40mm
A 8 PCS	B 8 PCS	C 8 PCS





5


6





		
±6*38mm	±15*11mm	±8*40mm
A 8 PCS	B 8 PCS	C 8 PCS

	
ST3.5*14mm	
D 16 PCS	H 4 PCS

7



	
ST3.5*14mm	
D 8 PCS	R 8 PCS